

CE EMC

Electric Bicycle User's Guide



LIGHT POWER & GREEN ENERGY

Introduction

By making the decision to use an electric bike you are helping to safeguard our environment by saving our planets precious and not adding to carbon pollution.

Thank for choosing this electric bicycle.

Our bikes are manufactured under rigorous control to the most stringent European and UAS safety standards and are constantly spot checked both here and in the factory. For many years we have been engaged in the research and development of electric bicycles and cars and this electric bicycle is the culmination of those efforts.

Before you use it, it is important that you read this manual carefully. If there is anything you do not understand completely please do not hesitate to.

Please observe traffic regulations, and don't lend your bicycle to anyone who is unfamiliar with it. The bicycle can only legally be used on the queen's highway by a person aged 14 years or older.

We strongly advise you to always wear a cycle helmet when using your bicycle and to attend a Cycle proficiency course prior to using on the open road. It is not a toy and should be considered as a serious mode of transport.

1. Before you set off

Check handlebars are properly tightened.

Check brake isolator is functioning properly.

Check tyre pressures are correct.

Make sure battery is fully charged.

Load battery into bicycle and turn on with power key.

Please read this manual carefully. Only on full understanding of all the functions of this electric bicycle should you use the product.

For your safety, please turn off the power key when stopped or walking the bike.

2. Battery care

2.1 Before setting off on any journey it is always better to have a fully charged battery.

2.2 Always remember that you use up to three times more power when setting off under the twist throttle or riding up steep hills.

To preserve the life of each charge always set off and climb hills using 1:1 pedal assist rather than the twist throttle.

- 2.3 Do not expose the bicycle or battery package to fire, extreme heat sources or alkaline substances.
- 2.4 When leaving your bicycle during hot weather always try to leave in a shaded well ventilated area.
- 2.5 For best results always recharge the battery at room temperature.
- 2.6 To maximize the life of the battery always leave it fully charged when not in use and if possible recharge once every 4 weeks.
- 2.7 Before unloading the battery, first raise the saddle and unload the battery using its handle.

Important notice

Worn out batteries should be disposed of properly or returned to us for a credit against the cost of a replacement.

3. Recharging your battery

- 3.1 First connect the output connector plug with the battery, and then connect to the mains. A red lamp on the charger indicates the battery is charging, when this turns green the battery fully charged. Please disconnect from the mains after charging. Always disconnect the charger from the mains before disconnecting from the battery. It is possible that the battery will take up to 6 hours to charge on the first three charges.
- 3.2 When charging the battery always do so in a ventilated area.
- 3.3 Do not leave the charger connected to the mains when not in use.

4. Water and your electric bicycle

- 4.1 Your electric bicycle is rain and splash proof and can be used in all weathers.
- 4.2 The electrical components of the vehicle, such as motor, battery, and controller, must not be submerged in water.

5. Maintenance and adjustments

- 5.1 Do not attempt to open the casing of the battery, motor, or regulator or all warranties will become void. If you experience a problem contact our service department.
- 5.2 Wheel spokes should be adjusted after 6 months. Handlebar and saddle tubes should never be on the nuts positioning the handlebar, handlebar vertical tube, bicycle saddle, saddle tube and front wheels is 18NM. The minimum torque on the nuts on the pedal bearing axle and rear wheel is 30NM.
- 5.3 If the chain becomes loose or frequently comes off the front cog, you can easily adjust the chain tension by loosening the rear axle nuts slightly, and adjusting the tension bolts. Make sure that the chain runs freely and re tighten the axle nuts.
- 5.4 The brake leavers should lock the wheels when compressed half way between their open position and touching the handlebars. When the need adjusting use the following methods:
 Front brake: Loosen the nuts the cable clamp, then tension or release the steel cable, until the gap between the wheel and brake rubber is 1.5 to 2.0 mm.
 Rear brake: Loosen the nuts on the cable clamp, then tension or release the steel cable until you can feel the brake lever's motion is fluid and does not lock the back wheel until it is the correct position.

Warning: Braking distances increase on wet or icy roads.

- 5.5 Regularly lubricate the gears and chain with light oil and the brake bushes (not the rubber brake shoes) with a little grease.

6. Introduction to Main components/parts



- | | | |
|----------------|------------------|---------------------|
| 1. front light | 7. quick release | 13. battery lock |
| 2. gear lever | 8. seat post | 14. rear derailleur |
| 3. brake lever | 9. quick release | 15. gears |
| 4. fork | 10. battery | 16. motor |
| 5. brake cable | 11. controller | 17. rear brake |
| 6. disc brake | 12. PAS | |

7. Technical specifications & performance

General specifications

Type	Electric bicycle
Max speed	32km/h
Net weight	24.5kgs
Max range	60km
Carrying load	100kgs
Wheelbase	1200mm
Dimension	1820*620*1000mm
Traveling noise	<60db
Energy consumption	per 100km<1.2kw/h

Battery specifications

Cell type	Lithium ion
Capacity	10Ah
Rate voltage	36V
Main Controller specifications	
Low voltage safeguard	31.5V
Overload current safeguard	16A

Main hub motor specifications

Motor type	Brushless with gears
Rated power	350W
Rated voltage	36V

8. Trouble shooting

Problem	Reasons for problem	Trouble shooting
Top speed too slow	1. low battery voltage 2. handlebar control problem 3. damage to motor driveline	1. recharge battery fully 2. call service 3. call service
Power on but motor not working	1. battery not connected position 2. fused 3. motor connection damaged 4. handlebar control problem	1. reinstall battery 2. replace fuse 3. call service 4. call service
Driving shorter distance per charge	1. type pressure too low 2. undercharge or charger fault 3. battery capacity loss or damage 4. hill climbing, frequent stop and start riding against strong wind or weight overload	1. check pressures, pump tyres 2. recharge complete or have charger inspected 3. replace battery 4. use 1:1 power assist
Charger not working	1. charger fuse blown 2. charger damage	1. replace fuse 2. call service

9. Repair or replacement of components

Only use this product in accordance with this user manual.

We offer a limited warrantee of on the following items.

9.1 Welds on the main frame, front forks, splashboard, or wheel rims.	Two years
9.2 Gears, bearings, motor shell, hub motor.	Two years
9.3 Handlebar controls, brakes (excluding rubber brake shoes), controller, charger, or battery capacity.	One year
9.4 Paintwork (excluding deliberate damage or scratching)	Six months
9.5 Front and rear axle, flywheel, chain wheel, or driveline	Six months
9.6 Battery casing, battery leak, battery capacity step-down more than 40%.	One year
9.7 Electro plating, on handlebars, wheel rims, crank, bracket, or kickstand.	Three months

Additional Limited Warrantees

1. If the product has any quality fault within 15 days if sale you may choose to have the bike repaired or replaced.
2. The period of assurance shall commence from the day the sale was made.
3. Beyond the period of assurance, we offer lifelong repair, but the cost of labor, parts and delivery will be charged.

Exception to Limited Warrantees

1. Damage resulting from misuse, not maintaining the vehicle or not following the guidelines within this user guide.
2. Accidental or deliberate damage.
3. Damage due to private repair by user or unauthorized service center.
4. Failure to produce invoice or proof of purchase.